



Bonding Procedures for NuVeneers

NuVeneers - Etching Procedure:

1. Porcelain Conditioner - 30 - Sec. Rinse, Dry.
2. Cerinate Prime - 30 Sec. Blow Thin.
3. Keep NuVeneers in proper order.

Try In Of NuVeneers :

1. Mix Try - In Paste and Opaquer, if used.
 2. Add Try - In To NuVeneers. Clean excess off with brush. (If same day, Tenure-S is ok to clean try-in paste out.)
 3. Choose Selection.
 4. Clean NuVeneers and Tooth with Brush and Tenure-S.
 5. Thin Tenure-S with Air. A thin film will be left on Both.
 6. Do Not Re-etch or Prime.
 - 7.
- *If not seating the same day, remove try-in paste with brush and re-etch with Hydrofluoric acid (not Pre-Etch). Rinse and place in order, back in box, for Delivery Day.*

Tooth :

1. Pumice - or porcelain polish paste, teeth, Rinse, Dry.
2. Etch - 20 Sec. with Etch and Seal, Rinse, Dry.
3. Mix together equal amounts of Tenure A & B.
Apply 5 coats to each tooth, Dry. If not glossy; Re-apply A & B until you get a nice and **glossy coating**. Blow thin. Apply thin coat of Tenure-S, blow thin . **Do Not Cure**.

Bonding :

1. Apply Ultra Bond Cement to NuVeneers, **Self Cure in 22 mins.**
2. Remove excess cement with brush coated with Tenure-S or dab sponge.
3. Tack with small tip - **1 sec.**
4. Keep cleaning with brush.
5. Cure all NuVeneers all around for **5 sec.**
6. Trim with fine burs, do finishing.
7. Final trim is in 24 hours for **Porcelain to Porcelain Only**. Schedule patient for final margin trimming at that time.